

DIGITAL VIDEO DISC PLAYER & VIDEO CASSETTE RECORDER

DVP3050V

User manual

Thank you for choosing Philips.

Need help fast?

Read your Quick-Use Guide and/or User Manual first for quick tips that make using your Philips product more enjoyable.

*If you have read your instructions and still need assistance, you may access our online help at **www.philips.com/support***



PHILIPS

Introduction

Thank you for purchasing this Philips DVD/VCR. This Owner's Manual explains the basic operation of this unit.

Environmental Information

All unnecessary packaging has been omitted. Packaging has been made easy to separate into three materials: cardboard (box), polystyrene foam (buffer) and polyethylene (bags, protective foam sheet). Your DVD/VCR consists of materials which can be recycled and reused if disassembled by a specialised company. Please observe the local regulations regarding the disposal of packaging materials, exhausted batteries and old equipment.



Supplied Accessories

- Remote control
- Batteries (two AA size) for Remote control
- RCA connector plug
- RF Coaxial cable
- Owner's Manual

Safety Information

- To reduce the risk of fire or electric shock, do not expose this device to rain or moisture.
- Before operating the DVD/VCR, check that the operating voltage indicated on the typeplate (or the voltage indication beside the voltage selector) is identical with the voltage of your local power supply. If not, please consult your dealer.
- Place the DVD/VCR on a flat, hard and stable surface.
- There must be sufficient room in front of the player for the disc tray to be opened.
- In cabinet, allow about 2.5cm (1inch) of free space all around the player for adequate ventilation.
- Do not expose your player to extreme of temperature or humidity.
- If the DVD/VCR is brought directly from a cold to a warm location, or is placed in a very damp room, moisture may condense on the lens of the disc unit inside the DVD/VCR player. Should this occur, the DVD/VCR would not operate normally. Leave the player on for about one hour with no disc in the DVD/VCR until normal playback is possible.
- The mechanical parts of the set contain self-lubricating bearings and must not be oiled or lubricated.
- Never spill liquid of any kind on this unit. If liquid is spilled into the unit, consult qualified service engineer.
- Do not stand the unit up vertically. Install the unit in a horizontal and stable position.
- Be sure to remove the disc and unplug the AC power cord from the output before carrying the unit.
- **When the DVD/VCR is switched to Standby mode, it is still consuming some power. To disconnect the system from the power supply completely, remove the AC power plug from the wall socket.**

General Information

The region code for this set is 5.

Since it is usual for DVD movies to be released at different times in different regions of the world, all players have region codes and discs can have an optional region code. If you load a disc of a different region code to your player, you will see the region code notice on the screen. The disc will not playback, and should be unloaded.



Manufactured under license from Dolby Laboratories. "Dolby" and the double-D symbol are trademarks of Dolby Laboratories.

This product incorporates copyright protection technology that is protected by U.S. patents and other intellectual property rights. Use of this copyright protection technology must be authorized by Macrovision, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision. Reverse engineering or disassembly is prohibited.



The DVD/VCR is in conformity with the EMC directive and low-voltage directive.

For Customer Use:

So that you can identify your machine for service questions or in the event of theft, enter the serial number here. The serial number (PROD. NO.) is printed on the type plate fixed at the back of the device.

Model No. DVP3050V

Serial No. _____

This product complies with the requirements of Directive 73/23/EEC +89/336/EEC +93/68/EEC.

Laser safety

This unit employs a laser. Due to possible eye injury, only a qualified service person should remove the cover or attempt to service this device.

USE OF CONTROLS OR ADJUSTMENTS OR OF PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.

LASER

Type	Semiconductor laser GaAlAs
Wave length	655 nm (DVD) 790 nm (VCD/CD)
Output Power	0.8 mW (DVD) 0.5 mW (VCD/CD)

CLASS 1 LASER PRODUCT
KLASSE 1 LASER PRODUKT
KLASS 1 LASER APPARAT
CLASSE 1 PRODUIT LASER

(WARNING LOCATION: ON THE BACK-PLATE OF SET)

About the PBC Function of Video CD

- This unit conforms to ver.1.1 and ver.2.0 of Video CD standard, with PBC function.
 - Ver.1.1 (without PBC function): You can enjoy playback picture as well as music CD.
 - Ver.2.0 (with PBC function): When using a Video CD with PBC function, "PBC" appears on the display.
- "PBC" stands for Play Back Control.
- Video CD with PBC function has its original menu. Menu operation may vary depending on the disc. Refer to the manual included in the disc for details.
- "PBC" appears on the front panel display when a Video CD with PBC function is loaded.

Contents

Introduction	
Environmental Information	2
Supplied Accessories	2
Safety Information	2
General Information	
Laser Safety	2
About the PBC Function of Video CD	2
Symbols Used in this Manual	3
Functional Overview	
Front Panel	4
Rear Panel	5
Remote Control	5
Setting Up your DVD/VCR	
Basic Connections	6
Connecting to a TV	6
Simplest connection using only supplied black RF Coaxial cable	6
Connecting to an Audio System (for DVD features)	6
Connecting to Optional Equipment (for DVD features)	6
External Input Mode (for VCR features)	7
Inserting batteries into the Remote Control	7
Using the Remote Control	7
Playable Video Tapes	7
Turning on your DVD/VCR	7
Video Channel Setting	7
Automatic Channel Setup	8
Manual Channel Preset	8
Follow TV (Automatic TV channels sorting)	8
Sorting TV channels manually	8
Setting the language	8
Setting the clock	8
Setting the RF out channel	9
Decoder allocation	9
VCR Playback	
Playing back video tape	9
Playing back NTSC video tapes	9
Displaying current video tape position	9
Searching for a video tape position with picture (scanning)	10
Still picture / slow motion	10
Searching for video tape position without picture (forward wind and rewind)	10
Index search	10
Manual Tracking	10
VCR Manual Recording	
General information	10
Recording without automatic switch-off	10
Lining up recordings (assemble cut)	10
Selecting the recording speed (SP or LP)	10
Automatic controlled recording from a satellite receiver (Record Link)	10-11
Direct Record	11
Switching Direct Record on or off	11
Direct dubbing	11
Copying a video tape	11
Programming a Recording (TIMER)	
General information	11
Programming a recording	12
OTR (One Touch Recording)	12
How to check, or delete a programmed recording (TIMER)	12
How to change a programmed recording (TIMER)	12
Hints for Timer Recording	12

Other Functions	
Changing the video (colour) system	12
Switching the status display off or on	13
Blue Background on or off	13
Clock Display	13
Selecting the sound channel	13

Paying a Disc	
Basic Playback	13
General Features	14
Pause	14
Disc Menus	14
Title Menu	14
Calling Up a Menu During Playback	14
Step by Step Playback	14
Resume	14
Fast Forward / Reverse Search	14
Slow Forward / Slow Reverse	14
Zoom	14
Track Search	14
Title / Chapter Search	15
Time Search	15
Repeat	15
Programmed Playback	15
Random Playback	15
MP3 / JPEG / Windows Media™ Audio Playback	16
Slide Show Mode	16
Dual Playback	16
Adjustment of Picture Size	16
On-Screen Information	16-17
Audio Language	17
Stereo Sound Mode	17
Subtitle Language	17
Camera Angle	17
Virtual Surround	17
Marker Setup Screen	17

DVD Setup	
Language Setting	17
Display Setting	17-18
Audio Setting	18
Parental Control	18
Others	18
To Reset All the Settings of the SET UP screen	18

Information	
Maintenance	19
Specifications	19
Troubleshooting	19

Symbols Used in this Manual

The below symbols appear in some headings and notes with the following meanings:


	– Description refers to playback of DVD-video discs
	– Description refers to playback of Audio CDs
	– Description refers to playback of Video CDs.
	– Description refers to playback of MP3 files
	– Description refers to playback of Windows Media™ Audio files
	– Description refers to playback of JPEG files

Helpful Hints!

- Some DVD video discs require specific functions or allow only limited functions during playback.
- “” may appears on the TV screen which means that the function is not available on that specific DVD video disc.
- Windows Media is a trademark of Microsoft Corporation.
- This unit is not compatible with Multiple Bit Rate (MBR: a file that contains the same content encoded at several different bit rates).

Functional Overview

Front Panel



1. **STANDBY-ON** (DVD,VCR)
to switch the DVD/VCR to ON or OFF
2. **POWER-ON light** (DVD,VCR)
light appears when DVD/VCR turns on.
3. **Cassette Compartment** (VCR)
insert a video tape here
4. **OPEN/CLOSE** (DVD)
to open/close the disc tray
5. **Disc Tray** (DVD)
insert a disc here
6. **D. DUBBING** (DVD,VCR)
to play DVD disc and record its content to video tape at the same time
7. **PLAY** (DVD)
to start, pause or resume disc playback
8. **STOP** (DVD)
to stop playback
9. **DVD light** (DVD)
light appears when DVD/VCR in DVD mode
10. **SOURCE** (DVD,VCR)
to select between DVD and VCR mode
11. **VCR light** (VCR)
light appears when DVD/VCR in VCR mode
12. **CHANNEL** (VCR)
to select a programme number on the TV
13. **IR (Infrared) Remote Sensor** (DVD,VCR)
receive signals from remote control

14. RECORD (VCR)

press once to start recording, repeatedly to start an One-Touch Recording

15. PLAY (VCR)

to play a video tape

16. STOP/EJECT (VCR)

when playback is stopped, press to eject the video tape

17. FFW (VCR)

when video tape playback is stopped, press to fast forward the video tape at high speed during playback, press to fast forward the video tape while the picture stays on the screen

18. REW (VCR)

when video tape playback is stopped, press to rewind the video tape at high speed during playback, press to rewind the video tape while the picture stays on the screen


19. AUDIO/VIDEO IN jacks

connect to AUDIO and VIDEO OUT of an audio source


Display Message

	Appears after the disc tray closes if the tray is empty, if there is an error reading the disc, or if an unacceptable disc is installed
	Tray is opening or is open.
	Tray is closing. This also may appear as the Player tries to load a Disc
	Loading the Disc
	Lights up when the playback control is activated

DVD




VCR



Functional Overview


Rear Panel



1. **MAINS (AC Power Cord)**
connect to a standard AC outlet
2. **OPTICAL (DIGITAL AUDIO OUT) jack (DVD only)**
connect to digital (optical) audio equipment

3. **COAXIAL (DIGITAL AUDIO OUT) jack (DVD only)**
connect to AUDIO inputs of a digital (coaxial) audio equipment
4. **ANALOG AUDIO OUT (Left/Right) jacks (DVD only)**
connect to AUDIO inputs of an amplifier, receiver or stereo system
5. **S-VIDEO OUT jack (DVD only)**
connect to a TV with S-Video inputs
6. **AV2 (DECODER) jack (VCR only)**
connect SCART cable or RCA cable with RCA connector plug from another DVD/VCR, camcorder or an audio/video source
7. **AV1 (TV) jack (DVD/VCR)**
connect SCART cable or RCA cable with RCA connector plug to a TV
8. **AERIAL jack**
connect to an antenna or cable
9. **RF OUT jack**
use supplied RF Coaxial cable to connect to the ANTENNA IN on your TV, cable box or Direct Broadcast System

Remote Control



1. **STANDBY-ON**
switch DVD/VCR ON or OFF
2. **0-9 numerical key pads/+10**
select numbered items in a menu
use +10 button to enter number 10 and above (DVD)
to select TV channels in VCR mode
3. **SYSTEM**
to change the video (colour) system
4. **VCR**
press to put the DVD/VCR in VCR mode and before using the remote control for VCR features
5. **DISC/VCR MENU**
to display the menu of the DVD disc or to access VCR menu
6. **OK**
acknowledge menu selection (DVD)
7. **▲ ▼ ◀ ▶**
(left/right/up/down) select an item in the menu
8. **◀▶**
to view DVD picture in fast reverse motion (DVD)
to rewind the video tape (VCR)
9. **STOP**
to stop a DVD disc playback (DVD)
to stop playback, recording(VCR)
10. **PLAY**
to start a DVD disc playback (DVD)
to start a video tape playback(VCR)

11. **MARKER**
Press to call back the Marker display (DVD)
12. **TITLE**
to display title menu of a disc (DVD)
13. **ANGLE**
select DVD camera angle (DVD)
14. **MODE**
to set up programmed or random playback (DVD)
15. **REPEAT**
repeat chapter, track, title, group, disc (DVD)
16. **TIMER SET**
to put the DVD/VCR into standby mode for a timer recording
17. **INDEX**
to fast forward or rewind the video tape at index number (VCR)
18. **SUBTITLE**
subtitle language DVD selector (DVD)
19. **SEARCH MODE**
to access or remove search display (DVD)
20. **REPEAT A-B**
repeat a specific segment (DVD)
21. **ZOOM**
enlarge DVD video image (DVD)
22. **RETURN**
to return previous or remove setup menu (DVD)
23. **AUDIO**
to choose audio languages or sound modes (DVD)
to choose sound modes (VCR)
24. **SLOW**
to view video tape playback in slow motion (VCR)
25. **RECORD**
to record the TV channel selected at this moment or press repeatedly to start a One-Touch Recording (VCR)
26. **PAUSE**
pause playback temporarily / frame-by-frame playback (DVD)
pause playback and during recording temporarily (VCR)
27. **▶▶**
to view DVD picture in fast forward motion (DVD)
to fast forward the video tape (VCR)
28. **SYSTEM MENU**
to access or remove the DVD setup menu (DVD)
29. **DVD**
press to put the DVD/VCR in DVD mode and before using the remote control for DVD features
30. **DISPLAY STATUS/EXIT**
to access or remove the display screen during DVD or Audio CD playback (DVD)
to access or remove VCR's on-screen status display (VCR)
to remove VCR's menu (VCR)
31. **CLEAR**
to reset the setting (DVD)
to reset the counter (VCR)
to delete last entry/Clear programmed recording (TIMER) (VCR)
to cancel the point for repeat A-B (DVD)
32. **SKIP/P**
to skip chapter/tracks (DVD)
to change TV channels (VCR)
33. **OPEN/CLOSE EJECT**
to insert discs into or remove them from the tray (DVD)
to remove the video tape from the VCR (VCR)

Setting Up your DVD/VCR

Basic Connections

- Please refer to the instruction books of your TV, VCR, Stereo System or other devices as necessary to make the best connections.
- Make one of the following connections, depending on the capabilities of your existing equipment.

The following guidelines are options for the best picture and sound quality available on your DVD/VCR.

Picture

- 1 Use SCART RGB Output (DVD/VCR(AV1 TV)) for best picture quality (for DVD and VCR features).
- 2 Use S-VIDEO Output for the better picture quality (for DVD features only).
- 3 If your TV only has a RF-style (Antenna IN or 75 ohm) input, use the RF OUT for connection and set your TV to channel 22 ~ 69 with the same channel for DVD/VCR is set (for DVD and VCR features).

Sound

- 1 Digital audio connections provide the clearest sound. Connect the DVD/VCR DIGITAL AUDIO OUT (either COAXIAL or OPTICAL) to your amplifier or receiver (for DVD features only).
- 2 Use SCART Output (DVD/VCR(AV1 TV)) for better sound quality (for DVD and VCR features).
If digital connections are not possible, connect the DVD/VCR ANALOG AUDIO OUT (Left and Right) to your amplifier, receiver, stereo or TV (for DVD features only).

Warning!

- **Never make or change connections with the power switched on.**
- **Connect the DVD/VCR directly to your TV, instead of eg. a VCR, to avoid distortion because DVD video discs are copy protected.**
- **Do not connect the ANALOG AUDIO OUT of DVD/VCR to PHONO IN of your amplifier or receiver.**
- **If you use the Euro audio/video cable, it is not necessary to connect the analog audio cable.**

Connecting to a TV

- 1 Connect the antenna or cable to the AERIAL of your DVD/VCR.
- 2 Connect the DVD/VCR (AV1 TV) on the DVD/VCR to the corresponding connector on the TV.

Note:


- **Ensure that the "TV" indication on SCART cable is connected to the TV set and "DVD" indication on SCART cable is connected to the DVD/VCR.**

If your TV has RCA jack, connect the DVD/VCR (AV1 TV) on the DVD/VCR with RCA Connector Plug to RCA jack on your TV.

If your TV is not equipped with a SCART input, you can select the following connection:

If your TV has a S-Video input connector,

- 1 Connect the antenna or cable to the AERIAL of your DVD/VCR.
- 2 Connect the S-VIDEO OUT on the DVD/VCR to the S-Video in on the TV.
- 3 Connect the ANALOG AUDIO OUT on the DVD/VCR to the Left and Right audio in on the TV.




Note:

- **You will still need the SCART cable or RF Coaxial cable for VCR features.**


Simplest connection using only supplied black RF Coaxial cable

- 1 Disconnect the antenna or cable from your TV.
- 2 Connect the antenna or cable to the AERIAL of your DVD/VCR.
- 3 Connect black RF Coaxial cable to the RF OUT on the rear panel of the DVD/VCR and to the ANTENNA IN on the TV.
- 4 Plug in the power cords of the TV and DVD/VCR.



Connecting to an Audio System (for DVD features)

- 1 You can also listen to the sound of audio CDs and DVD video discs by connecting to an optional stereo system.
- 2 Connect DVD/VCR ANALOG AUDIO OUT (Left and Right) to the audio in on the stereo system.




Connecting to Optional Equipment (for DVD features)

- A digital component with a built-in MPEG 2 or Dolby Digital decoder allows you to enjoy the surround sound while producing the effect of being in a movie theater or a concert hall.
- The player outputs the surround sound signals from the COAXIAL or OPTICAL DIGITAL AUDIO OUT.

If your receiver has a MPEG 2 or Dolby Digital decoder, Connect the COAXIAL or OPTICAL DIGITAL AUDIO OUT of the DVD/VCR to the COAXIAL or OPTICAL DIGITAL AUDIO IN on your receiver.

Notes:

- **If the audio format of the digital output does not match the capabilities of your receiver, the receiver will produce a strong, distorted sound or no sound at all.**
- **You will still need the video cable or RF Coaxial cable for VCR features.**




Setting Up your DVD/VCR

External Input Mode (for VCR features)

To receive the signal from an external input (decoder, satellite receiver, video camera, another VCR etc.), connect to the AV2 (DECODER) socket, and enter '0.0.2.' with numerical key pads to appear "AV2" on the TV screen.
If you use the AV1 (TV) socket, enter '0.0.1.' with numerical key pads to appear "AV1" on the TV screen.
If you use the front AUDIO/VIDEO IN jacks, enter '0.0.3.' with numerical key pads to appear "AV3" on the TV screen.

Inserting batteries into the Remote Control

- 1 Open the battery cover.
- 2 Insert batteries (AA size) with the correct polarity as indicated by the + and - symbols inside the battery compartment.
- 3 Close the cover.



CAUTION!

- Remove batteries if they are exhausted or not to be used for a long time.
- Do not use old and new or different types of batteries in combination.
- Batteries contain chemical substances, so they should be disposed off properly and kept away from children.

Using the Remote Control

- Direct the remote control at the remote sensor of the DVD/VCR.
- Do not drop the remote control.
- Do not leave the remote control near extremely hot or humid place.
- Do not spill water or put anything wet on the remote control.


Playable Video Tapes

Philips Consumer Electronics recommends that only video tapes that have the VHS mark and High Quality (HQ) system is compatible with this unit. This unit has an Automatic Head Cleaner.

Recording Prevention

Video tapes have record tabs to ensure recordings are not erased accidentally.

- 1 To prevent recording, break off the tab with a screw-driver.
- 2 To allow recording, cover the hole with cellophane tape.



Notes:

- Use only video tapes with VHS mark.
- Remove any adhesive stick-on notes from the video tape before inserting into the DVD/VCR.
- Periodic maintenance is required to maintain your DVD/VCR performance.
- Video heads will require replacement after a period of time. Only an authorised service center should perform this service.

Turning on your DVD/VCR

The following steps only be performed when you insert the AC PLUG at the first time.

- 1 Turn on the TV and select the video channel on the TV.
- 2 Plug in the DVD/VCR.
- 3 Press ▲/▼ repeatedly to select your desired language.
- 4 Press DISC/VCR MENU.
- 5 Confirm with P+.
- 6 The Auto Tuning starts.
- 7 "TIME" and "DATE" will appear on the TV screen.
- 7 Check "TIME". If required, please change the time with numerical key pads.
- 8 Check if the displayed settings for "DAY", "MONTH" and "YEAR" are correct.
- 9 When all information is correct, save by pressing STATUS/EXIT. The preparation for use is now complete.

SELECT ▲▼
→ ENGLISH
ČESKY
MAGYARUL
POLSKI
РУССКИЙ
PUSH MENU TO CONTINUE

PLEASE WAIT
START FINISH

TIME 10:00
DATE 25/ 12/ 05
SMART CLOCK [ON]
END=EXIT

Note:

- When Auto Tuning has been completed, the initial settings menu will not appear even if the AC plug has been unplugged or after a power failure. To recall this initial settings menu, press SOURCE and VCR PLAY ► on the system's front panel at the same time for more than 2 seconds when the power is off.

Video Channel Setting

Video channel setting will be necessary, if your DVD/VCR is connected to the TV via the RF Coaxial cable.

- 1 Insert a pre-recorded video tape into the DVD/VCR. The DVD/VCR will turn on and start playback automatically. If playback does not start, press PLAY ►.
- 2 Select and adjust your TV to channel 36.
 - If the playback picture appears on the TV screen, continue with step 8.
 - If channel 36 is employed for broadcasting, or interference lines appear on the picture, the RF converter must be set to a different channel between CH22 and CH69. Continue with step 3.
- 3 Press DISC/VCR MENU.
- 4 Press ▲/▼ to select "INITIAL SET UP". Then, press ►.
- 5 Press ▲/▼ to select "RF OUT". Then, press ► twice.
- 6 Press ▲/▼ to select a channel which is not used for broadcasted between channel 22 and channel 69 in your area, then press ►.
 - You can also see the selecting RF channel in the display.
- 7 Press ▲/▼ to select "TV SYSTEM". Then, press ►.
- 8 Choose "K" or "G". Then, press ►.
- 9 Press STATUS/EXIT to exit. Set the TV channel to the RF OUT CHANNEL which was selected on the DVD/VCR. A picture from the VCR will appear on the TV screen. If a picture does not appear, repeat steps 3 to 7 using a different channel which is not used for broadcasted.
- 10 Press STOP ■ to stop the video tape.

SELECT ▲▼ CHOOSE ►
→ RF OUT CH 36
TV SYSTEM K
SET=0-9
END=EXIT

Note:


- You may also access the RF OUT CH menu by pressing and holding DISC/VCR MENU for 3 seconds during power off until the RF OUT CH menu appears.

Setting Up your DVD/VCR

Automatic Channel Setup


You can programme the tuner to scan only the channels that you can receive in your area.

- 1 Turn on the TV and select the video out channel on your TV.
- 2 Press VCR, then DISC/VCR MENU.
- 3 Press ▲/▼ to select "TUNER SET UP", then press ►.
- 4 Press ▲/▼ to select "AUTO TUNING", then press ►.
 - The tuner scans and memorises all the active channels in your area. After scanning, the tuner stops on the lowest memorised channel.
- 5 Press P+/P- or numerical key pads to scan through channels you have received.



Manual Channel Preset

- 1 Press VCR, then DISC/VCR MENU.
- 2 Press ▲/▼ to select "TUNER SET UP", then press ►.
- 3 Press ▲/▼ to select "MANUAL TUNING", then press ►.
- 4 Press ▲/▼ to select "PROG.", then press ►.
- 5 Press ▲/▼ or numerical key pads to select your desired programme number, then press ►.
 - You can select programme number 01-99.
 - If "ON" appears on the right side of "SKIP", press ▲/▼ to select "SKIP". Then, press ► to select "OFF".
- 6 Press ▲/▼ to select "CHANNEL", then press ►.
- 7 Press ▲/▼. The DVD/VCR tuner will begin to search up or down automatically. When a channel is found, the DVD/VCR will stop searching and the picture will appear on the TV Screen.
 - You can select desired channel number by using numerical key pads. Press three digits to select the channel number. (To select channel 24, first press 0 button then press 2 and 4.)
 - If this is the channel you want, press ►.
 - If you want to remove scrambled signals, press ▲/▼ to select "DECODER". Then, press ► to select "ON".
- 8 Press STATUS/EXIT to exit.



Notes:

- To confirm that a channel has been added, press the P+/P- buttons.
- You should select the satellite channels to be received by the satellite receiver directly on the receiver itself.


How do I change "VIDEO MODE"?

If you want to change the video mode, select "VIDEO MODE" with ▲/▼. Then, press ► to select your desired mode.

Follow TV (Automatic TV channels sorting)

When the automatic channel search function is activated, the TV channels are saved in a specific order. This may vary from the order of TV channels on the TV. This function changes the order of TV channels saved in the DVD/VCR to match that of the TV. Make sure that the DVD/VCR and the TV are connected by a SCART cable.

- 1 Press VCR, then DISC/VCR MENU.
- 2 Press ▲/▼ to select "TUNER SET UP", then press ►.
- 3 Press ▲/▼ to select "FOLLOW TV", then press ►.
- 4 "P:01" will appear in the DVD/VCR display.



I cannot switch my TV to programme number "1"

If you have connected additional devices to socket AV2(DECODER), please disconnect these devices. Because of other connected devices, the TV could switch to the programme number of the scart socket.

"NO TV SIGNALS" appears in the TV screen.

The DVD/VCR is not receiving a video signal from the TV. Check the plug on the SCART cable. Check your TV's operating instructions to see which scart socket is used for video signals. If this does not help, it's not possible to use this function. Please read the section **Sorting TV channels manually**.

- 5 Select programme number "1" on the TV.
- 6 Confirm with ► on the DVD/VCR remote control. The DVD/VCR compares the TV channels on the TV and the DVD/VCR. If the DVD/VCR finds the same TV channel as on the TV, then it stores it at "P01".
- 7 Wait until the next number, e.g. 'P:02' appears in the display.
- 8 Select the next programme number on the TV, e.g. "2".
- 9 Confirm with ►.
- 10 Repeat steps 7 to 9 until you have assigned a programme number to all TV channels.
- 11 To end, press STATUS/EXIT.


Sorting TV channels manually

After you have performed the automatic channel search you may not agree with the sequence in which the individual TV channels have been allocated to the programme positions (programme numbers) of the DVD/VCR. You can use this function to individually sort the TV channels already saved.

The clock resets automatically

If you save a TV channel that transmits VPS/PDC or the Teletexte on programme number "P01", date and time will constantly be updated. As a result, time changes, i.e. daylight savings time, will be set automatically.


- 1 Press VCR, then DISC/VCR MENU.
- 2 Press ▲/▼ to select "TUNER SET UP", then press ►.
- 3 Press ▲/▼ to select "MOVE", then press ►.
- 4 Press ▲/▼ to select the saved TV channel that you want to change.
- 5 Confirm with ►.
- 6 Move the selected channel with ▲/▼ to the programme number you want to assign.
- 7 Confirm with ►.
- 8 To assign other TV channels to a programme number, repeat steps 4 to 7.
- 9 Confirm the assignment of the TV channel with MOVE menu.
- 10 To exit the MOVE menu, press STATUS/EXIT.



Setting the language

You can change the language for the TV screen menu. However, the DVD/VCR display will only display English text regardless of this setting.

- 1 Press VCR, then DISC/VCR MENU.
- 2 Press ▲/▼ to select "INITIAL SET UP", then press ►.
- 3 Press ▲/▼ to select "LANGUAGE", then press ►.
- 4 Select the desired language with ▲/▼.
- 5 To end, press STATUS/EXIT.




Setting the clock

If the display shows an incorrect time or "--:--", the time and date must be reset manually.

If a TV channel that transmits VPS/PDC or the Teletexte is stored under programme number "P01", time/date will automatically be taken from VPS/PDC or the Teletexte information. (Smart Clock)

- 1 Press VCR, then DISC/VCR MENU.
- 2 Press ▲/▼ to select "INITIAL SET UP", then press ►.
- 3 Press ▲/▼ to select "CLOCK", then press ►.



VCR Playback

- 4 Check the time in "TIME".
If required, please change the time with numerical key pads.
- 5 Check "DAY", "MONTH" and "YEAR" in the same way.
- 6 Choose "SMART CLOCK ON" or "OFF" with ►.
- 7 To end, press STATUS/EXIT.

Time/date is displayed incorrectly despite manual setting
With Smart Clock, time/date is taken from the TV channel saved on "P01".

If you wish to switch this automatic time correction off, select "OFF" for Smart Clock.
You can reactivate this function at anytime by selecting "ON" for Smart Clock.

Setting the RF out channel

In some reception locations it is possible that a TV channel will be sent on the same or similar frequency as the DVD/VCR.
Result: As soon as the DVD/VCR is switched on, the reception quality for this or several other TV channels will decrease.

The following steps will show you how to change the pre-set 'transmission' (RF out channel) frequency on the DVD/VCR.

- 1 Press VCR, then DISC/VCR MENU.
- 2 Press ▲/▼ to select "INITIAL SET UP", then press ►.

What is RF out channel?

This electronic component in the DVD/VCR allows the device to transmit audio and video signals via the aerial cable. These signals can be received on a TV set just like TV channels.

What is RF out channel frequency?

This frequency or channel indicates the channel on which the audio or video signal is transmitted.

- 3 Press ▲/▼ to select "RF OUT", then press ►.

- 4 Press ►.

- 5 Press ▲/▼ or numerical key pads to select a free (not allocated) channel between channel 22 and 69 in your area.

- 6 Press ►.

- 7 Select "TV SYSTEM" with PLAY ► or STOP ■.

- 8 Choose "K" or "G" with ►.

- 9 To end, press STATUS/EXIT.

SELECT ▲ ▼ CHOOSE ►
→ RF OUT CH 36
TV SYSTEM K
END=EXIT

If you cannot get an interference-free picture and sound, connect the DVD/VCR and the TV with a SCART cable. Then, switch the built-in modulator off.

Press ▼ repeatedly until "---" appears next to "RF OUT CH" on the TV screen.
Then confirm with ►.

Decoder allocation

Some TV channels transmit encoded TV signals which can only be viewed with a purchased or rented decoder. You can connect such a decoder to this unit. The following function will automatically activate the connected decoder for the desired TV channel.

- 1 Switch the TV on. If applicable, select the programme number for the DVD/VCR operation.
- 2 Press ▲/▼ or numerical key pads to select the TV channel which you would like to allocate the decoder to.
- 3 Press DISC/VCR MENU. The main menu will appear.
- 4 Press ▲/▼ to select "TUNER SET UP". Then press ►.
- 5 Press ▲/▼ to select "MANUAL TUNING". Then press ►.
- 6 Press ▲/▼ to select "DECODER".
- 7 Press ► to select "ON" (Decoder switched on).
- 8 To end, press STATUS/EXIT.

MANUAL TUNING
PROG. P55
CHANNEL 055
→ DECODER [OFF]
SKIP [OFF]
VIDEO MODE [SECAM]
SELECT ▲ ▼ CHOOSE ►
END=EXIT

How can I switch off the decoder?

Use ► to select "OFF" (Decoder switched off).

Playing back video tapes

You can operate the DVD/VCR using the remote control or the buttons on the front of the DVD/VCR. If you press PLAY ►, STOP ■, ◀◀ or ▶▶ while the set is in Stand-by, the power will be automatically turned on. Additionally, if a video tape was already inserted, the corresponding operation will be performed. Your DVD/VCR can only record and playback standard VHS video tapes.

- 1 Put a video tape into the cassette slot. The video tape is inserted automatically.
- 2 Press PLAY ► to view the video tape. '►' will appear on the display.
- 3 To stop the playback, press STOP ■ or STOP/EJECT ▲ on the DVD/VCR.
- 4 To eject the video tape, press EJECT ▲ or STOP/EJECT ▲ on the DVD/VCR when the DVD/VCR stops the playback.

DIGITAL STUDIO PICTURE CONTROL

Philips has developed a system which produces the best possible playback quality. For old and often-used video tapes, this system reduces interference. For new or high quality video tapes, it emphasises the details.

Picture/ sound quality is poor

When playing back rental videos or older, poorer quality video tapes, it may not be possible to completely filter out picture and sound interference. This is not a fault in your machine. Read the section **Manual Tracking**.

Do I need to change the playback speed when playing back LP recordings?

During playback, the correct speed will automatically be selected. For more information, please read the section **Selecting the recording speed (SP or LP)** in the chapter **VCR Manual Recording**.

Playing back NTSC video tapes

This unit can also playback video tapes that have been recorded in SP [Standard Play] or SLP [Super Long Play] mode in the NTSC standard (for example, American video tapes). However, this only works on PAL-television sets that are suitable for a picture frequency of 60Hz.

Displaying current video tape position

The following information is displayed on the screen:
e.g.: "0:02:45" shows the counter in hours, minutes and seconds.

"SP/LP" will show the recorded speed of your video tape
"REM 0:06" will show the remaining time left on the video tape in hours and minutes.

When you playback an NTSC video tape, the DVD/VCR will show "REM ---".

How can I set the counter to "0:00:00"?

You can set the counter to "0:00:00" with CLEAR.

When you put a video tape in the DVD/VCR, the counter will automatically reset to "0:00:00".

The counter does not move

This occurs when there are no recordings on a portion of a video tape. This is not a fault in your DVD/VCR.

The screen shows "-0:01:20"

If you rewind a video tape from the video tape position "0:00:00", the counter will show for instance, "-0:01:20" (the video tape was rewound to 1 minute and 20 seconds before "0:00:00").

"---" is displayed in the "REM" counter

This counter will automatically recognise the length of the video tape.

In addition, when you put in a video tape the DVD/VCR will first calculate the time played. Therefore, "---" appears first and only after the video tape has been running for a few seconds, the correct remaining time will be shown.

VCR Playback

Searching for a video tape position with picture (scanning)

- 1 During playback, press ◀◀ or ▶▶ one or more times.
- 2 If you want to search in super high speed, press ◀◀ or ▶▶ once more. (This function will not operate for a video tape recorded in SP mode in the NTSC standard.)
- 3 Press PLAY ▶ to resume playback.

Still picture / slow motion

- 1 During playback, press PAUSE ■■ to stop the video tape and display a still picture.
- 2 During playback, press SLOW to playback the video tape in slow motion.
- 3 Press PLAY ▶ to resume playback.
Scanning and still/slow motion interferes with the picture quality. The sound is switched off. This is not a fault in your DVD/VCR.

Searching for video tape position without picture (forward wind and rewind)

- 1 Stop the video tape with STOP ■.
- 2 Press ◀◀ or ▶▶. 'Fr' or 'FF' will appear on the display for 5 seconds, and then, the remaining video tape time will appear.
- 3 To stop the video tape, press STOP ■.

VCR Manual Recording

General information

Use **Manual Recording** to make a spontaneous recording (for example, a programme currently being shown).
If you want to start and stop a recording manually, read the section **Recording without automatic switch-off**.
Read the section **Direct Record** if you want to record a programme currently being shown.
Read the section **Automatic controlled recording from a satellite receiver (Record Link)**, if you want a recording to be controlled automatically by a satellite receiver.

Recording without automatic switch-off

- 1 Insert a video tape.
- 2 Use P+/P- to select the programme number you want to record, for example, 'P01'.
- 3 To start recording, press RECORD ●.
- 4 Stop recording with STOP ■.

"PROTECTED CASSETTE CANNOT RECORD"
message briefly appeared in the TV screen, then the video tape was ejected.

A video tape without its security tab was inserted.
Undo the erase protection.

Lining up recordings (assemble cut)

When you add a further recording to a video tape, which already has a recording on it, a short blank (flicker) can appear between the old and the new recording or the picture itself can flicker. To help reduce these from occurring, proceed as follows:

- 1 Find the video tape position of the old recording where you want to insert the new recording.
- 2 Look at the last minute of the old recording (playback).
- 3 Press PAUSE ■■ at the video tape position where the new recording is to go and press RECORD ●.
- 4 Now start recording as usual by pressing RECORD ● on the remote control.
- 5 Stop recording with STOP ■.

Index search

Every time a video tape is recorded an index marking is written on the video tape. These marked positions can be found again quickly and easily later.

- 1 To search for the previous marking, press INDEX ► and then ◀◀. 'Fr' will appear on the display for 5 seconds, and then, the remaining video tape time will appear.
- 2 For the next marking, press INDEX ► and then ▶▶. 'FF' will appear on the display for 5 seconds, and then, the remaining video tape time will appear.
- 3 As soon as the DVD/VCR finds this marking, it automatically switches to playback.

Manual Tracking

To manually adjust the tracking during playback and slow motion playback, press P+/P-.
Tracking will return to Automatic Tracking Adjustment when you press STOP ■, insert a video tape, or press PLAY ▶.
To remove vertical jitter in a Still picture, press P+/P-.

Selecting the recording speed (SP or LP)

LP allows to double the recording duration on video tape (for example 6 hours instead of 3 hours on an E180 video tape).

- 1 Switch on the TV set. If required, select the programme number for the DVD/VCR.
- 2 Press DISC/VCR MENU. The main menu will appear.
- 3 Select "RECORD SETUP" using ▲/▼ and confirm with ►.
- 4 Select "RECORD SPEED" using ▲/▼.
- 5 Select the required recording speed with ►.

SELECT ▲▼ CHOOSE ►
→ RECORD SPEED [SP]
DIRECT RECORD [OFF]
RECORD LINK [OFF]
END=EXIT

"SP" / "LP" / "AUTO"

"SP": Standard Play (normal recording speed) offers the usual first-class picture quality.
"LP": Long Play (half recording speed, double recording time). 6 hours can be recorded on a 3-hour video tape (E180) with a somewhat reduced picture quality.
"AUTO": AUTOMATIC Long Play. If there is not enough space on the video tape to record a programmed recording in standard speed, the recording is automatically done in "LP" (Long Play). Otherwise, the recording speed will be "SP" (Standard Play).

- 6 To end, press STATUS/EXIT.

Automatic controlled recording from a satellite receiver (Record Link)

This function automatically starts recording on the switched-off DVD/VCR when a video signal is recognised through the connected SCART cable. If your satellite receiver has a programming function, the recording will start automatically (as long as the satellite receiver is switched on).

- 1 Use a SCART cable to connect scart socket AV2 (DECODER) on the DVD/VCR to the corresponding scart socket on the satellite receiver.
- 2 Switch on the TV. If required, select the programme number for the DVD/VCR.
- 3 Press DISC/VCR MENU. The main menu will appear.

VCR Manual Recording

- 4 Select "RECORD SET UP" with ▲/▼ and confirm with ►.
- 5 Select "RECORD LINK" with ▲/▼.
- 6 Select function "ON" with ►.
- 7 To end, press STATUS/EXIT.

Switching off Record Link

To switch off the function, select "OFF" with ►.

- 8 Insert a video tape.
- 9 Programme the satellite receiver with the required information (programme number of the TV channel, start time, end time). If necessary, please see the operating instructions for your satellite receiver.
- 10 Press TIMER SET. The DVD/VCR is now ready to record. The beginning and end of the recording is controlled via scart socket AV2 (DECODER).

SELECT ▲ ▼ CHOOSE ►

RECORD SPEED	[SP]
DIRECT RECORD	[OFF]
→ RECORD LINK	[OFF]

END=EXIT

Direct Record

With Direct Record, you can record the right TV channel in seconds even if your DVD/VCR is switched off. If the recording is started manually, the DVD/VCR uses the current TV channel set on the TV. You will find more information on how to switch Direct Record on or off in the next section. Make sure that your DVD/VCR socket (AV1/TV) and the TV are connected by a SCART cable.

- 1 On the TV, select the programme number you want to make the recording from.
- 2 Press RECORD ● with the DVD/VCR switched off.
- 3 Stop recording with STOP ■.

How does Direct Record work?

The DVD/VCR compares the TV channel selected on the TV with its stored TV channels via the SCART cable. If the same TV channel is found, it switches the DVD/VCR to the corresponding programme number and starts recording. Please do not change the TV channel on the TV during the search so as not to affect the process.

Switching Direct Record on or off

- 1 Switch on the TV. If required, select the programme number for the DVD/VCR.
- 2 Press DISC/VCR MENU. The main menu will appear.
- 3 Select "RECORD SET UP" with ▲/▼ and confirm with ►.
- 4 Select "DIRECT RECORD", with ▲/▼. Select "OFF" (Direct Record off) or "ON" (Direct Record on) with ►.
- 5 To end, press STATUS/EXIT.
- 6 Press STANDBY-ON ○.

SELECT ▲ ▼ CHOOSE ►

RECORD SPEED	[SP]
→ DIRECT RECORD	[OFF]
RECORD LINK	[OFF]

END=EXIT

Direct dubbing

Follow the steps below to copy a DVD or video disc to a video tape. This will be possible only if the DVD is not copy protected.

- 1 Put a video tape in the cassette compartment. Make sure the video tape's record tab is intact and the video tape is long enough to record the disc.
- 2 Press VCR.
- 3 Select the recording speed. Details are at **Selecting the recording speed (SP or LP)**.
- 4 Put the DVD you want to copy in the disc tray.
- 5 Press DVD.
- 6 Press PLAY ►. While disc is playing, press PAUSE ■ at the point you wish to start recording.
- 7 Press D. DUBBING to record.

To pause the recording: Press VCR, then PAUSE ■.

To resume recording: Press PAUSE ■ again.

To stop the recording: Press VCR, then STOP ■.

Copying a video tape

You can make copies of video tapes made by friends or relatives for your own enjoyment.

WARNING:

Unauthorized recordings of copyrighted video tapes may be an infringement of copyright laws.

Connect the recording DVD/VCR (this unit) and the playback video recorder (another video recorder) by using scart socket AV2 (DECODER) or front AUDIO/VIDEO IN jacks.

- 1 Insert a pre-recorded video tape into the playback DVD/VCR.
- 2 Insert a blank video tape, or one you want to record over, into the cassette compartment of this unit.
- 3 Select programme number AV2 or AV3 on this unit.

Programme numbers of AV2 scart socket and front AUDIO/VIDEO IN jacks

If you are using the scart socket AV2 (DECODER), select programme number AV2 with 0.0.2.

If you are using the front AUDIO/VIDEO IN jacks, select programme number AV3 with 0.0.3.

- 4 Press RECORD ● on the front panel of this unit.
- 5 Begin playback of the video tape in the playback DVD/VCR.
- 6 To stop recording, press STOP ■ on this unit, then stop playback of the video tape in the playing DVD/VCR.

- For the best results during dubbing, use the DVD/VCR's front panel controls whenever possible. The remote control might affect the playback DVD/VCR's operation.
- If video or colour fades in and out, you may be copying a copy guarded video tape.

Programming a Recording (TIMER)

General information

Use a TIMER programming to automatically start and stop a recording at a later time or date. The DVD/VCR will switch to the right programme number and begin recording at the correct time. With this unit, you can pre-programme up to 8 recordings within a period of one year. To make a programmed recording, your DVD/VCR needs to know:

- * the date you want to make the recording
- * the programme number of the TV channel
- * the start and stop time of the recording
- * VPS or PDC on or off

This information is saved in a TIMER block.

What is "VPS/PDC"?

"VPS" (Video Programming System)/ "PDC" (Programme Delivery Control) are used to control the start and duration of TV channel recordings. If a TV programme starts earlier or ends later than scheduled, the DVD/VCR will turn on and off at the correct time.

What do I need to know about "VPS/PDC"?

Usually the VPS or PDC time is the same as the start time. But if your TV guide shows a VPS or PDC time which is different from the programme's scheduled start time, e.g. 20.10 (VPS/PDC 20.14), you must enter the VPS/PDC time exact to the minute. If you want a start time different from the VPS/PDC time, you must switch VPS/PDC off.

Programming a Recording (TIMER)

Programming a recording

- 1 Press VCR, then DISC/VCR MENU.
- 2 Select "TIMER" with ▲/▼. Then press ►.
- 3 Select "ONCE", "DAILY", or "WEEKLY" recording with ▲/▼. Then press ►.
If all Timer blocks are in use, "FULL" will appear on the OSD.
- 4 Select the desired Timer block with numerical key pads. (The flashing number indicates an empty TIMER block.)
- 5 Enter the Start time (START) End time (STOP), Programme number (PROG.), VPS/PDC information and the Date with numerical key pads.

SELECT ▲ ▼ CHOOSE ►
→ ONCE
DAILY
WEEKLY
TIMER LIST
END=EXIT

Programme numbers of the "AV1", "AV2" scart socket and "AV3" (AUDIO/VIDEO IN jacks)


You can also programme recordings from external sources via scart socket AV1(TV), AV2 (DECODER) or AV3 (front AUDIO/VIDEO IN jacks). Select programme number "AV1" with 0.0.1, "AV2" with 0.0.2 or "AV3" with 0.0.3.

- 6 When all inputs are correct, press STATUS/EXIT. The programming information is stored in a TIMER block.
- 7 Insert a video tape with an intact security tab (unprotected).
- 8 Press TIMER SET.

OTR (One Touch Recording)

This function enables you to set a recording length simply by pressing RECORD ●.

- 1 Follow steps 1 to 2 in **Recording without automatic switch-off** section.
- 2 Press RECORD ● repeatedly until the desired recording length appears in the upper left corner of the TV screen.



• Recording stops when 0:00 is reached.

To check time remaining during an OTR
Press DISPLAY.

To change the recording length during an OTR

Press RECORD ● repeatedly until the desired length appears.

To stop an OTR before recording is finished

Press STOP ■.

To cancel the OTR but continue recording

Press RECORD ● repeatedly until "REC" appears in the upper left corner of the TV screen.

How to check, or delete a programmed recording (TIMER)

- 1 Press VCR, then DISC/VCR MENU.
- 2 Press ▲/▼ to select "TIMER", then press ►.
- 3 Press ▲/▼ to select "TIMER LIST", then press ►.
- 4 Select timer block with ►.

SELECT ▲ ▼ CHOOSE ►
ONCE
DAILY
WEEKLY
→ TIMER LIST
END=EXIT

Timer block disappeared when I pressed ►.

You have checked all the programmed recordings. If you want to check them again, repeat steps 1 to 4.

- 5 To cancel the recording, press CLEAR.
- 6 To end, press STATUS/EXIT.
- 7 Press TIMER SET.

How to change a programmed recording (TIMER)

- 1 Press VCR, then DISC/VCR MENU.
- 2 Press ▲/▼ to select "TIMER", then press ►.
- 3 Press ▲/▼ to select "ONCE", "DAILY", or "WEEKLY" recording with ▲/▼, then press ►.
- 4 Select a TIMER block with numerical key pads. (The flashing number indicates an empty TIMER block.)
- 5 Press CLEAR to delete information and input correct information with numerical key pads.
- 6 To end, press STATUS/EXIT.
- 7 Press TIMER SET.

ONCE
TIMER - 1 2 3 4 5 6 7 8 -
SELECT TIMER NUMBER
END=EXIT

Hint for Timer Recording

- If there is a power failure or the DVD/VCR is unplugged for more than 1 minute, the clock setting and all timer settings will be lost.
- If a video tape ends during TIMER RECORDING, the DVD/VCR will stop, eject the video tape, and switch to the DVD mode automatically as '⏏' blinks. (If the DVD power is off, the DVD/VCR will become the STANDBY status).
- If a video tape is not in the DVD/VCR or does not have a record tab, '⏏' flashes and timer recording will not operate. Please insert a recordable video tape.
- When timer recordings are set, '⏏' will come on. To use the DVD/VCR as usual until the time for the recording, press TIMER SET so that '⏏' disappears. Press VCR to choose VCR mode, then continue with the other features as described in this manual.

Note:

- When all the programmed recording are finished, '⏏' will flash.

This is not a malfunction.

To use the DVD/VCR, press TIMER SET to turn off '⏏'.

When the recording has been programmed in VCR mode, "PRESS TIMER SET BUTTON FOR TIMER RECORDING" appears on the screen.

* Press TIMER SET to start the programming.

Error message: "FULL"

- If this error message appears after you select "ONCE", "DAILY", or "WEEKLY" on TIMER menu and press ►, then all TIMER blocks are already programmed. No more recordings can be programmed. If you want to clear or check a programmed recording (TIMER block), select the programme number on timer list menu and press CLEAR.

Other Functions

Changing the video (colour) system

If you playback recordings made on other video recorders or you want to record from external sources (via the scart socket), the automatic video (colour) system switch-over may lead to colour distortion.

You can switch off the automatic TV system switch-over as follows.

Video (colour) systems

Other countries, other video (colour) systems:

In central Europe transmissions are broadcast in the PAL system (Phase Alternation Line) standard. France uses SECAM (Séquentiel à mémoire). Middle Eastern countries use MESECAM (Middle East-SECAM). In some countries (USA and Japan), TV viewers receive their programmes as an NTSC signal (National Television System Committee).

- 1 Press SYSTEM on the remote control to select the TV (colour) system with the least disruptions during playback. Each pressing SYSTEM, the display will change cyclically; AUTO, ME-SECAM, PAL.



- 2 After 5 seconds, the OSD will disappear.

Other Functions

Switching the status display off or on

Along with the on screen menu, the status display also displays information on the current operating status (counter, playback, recording, TV channel, etc.) on the TV screen. You can switch off the information about the operating status so that the status display is not recorded when copying video tapes.

- 1 Press VCR, then DISC/VCR MENU.
- 2 Press ▲/▼ to select "VCR SET UP", then press ►.
- 3 Press ▲/▼ to select "STATUS DISPLAY", then press ►.
- 4 Press ▲/▼ to select "ON" or "OFF", then press ►.
- 5 To end, press STATUS/EXIT.

SELECT ▲ ▼ CHOOSE ►
 →STATUS DISPLAY [ON]
 BLUE BACKGROUND [ON]
 CLOCK DISPLAY [ON]
 END=EXIT

Which settings can I choose?

"ON": Shows the status display for a few seconds only.
 "OFF": Switches off the status display.

Blue Background on or off

If you want the TV screen to be solid blue when a weak signal is received, set "BLUE BACKGROUND" to "ON". The screen will be blue and the sound will be muted. Or, if you want to receive the weak signal, set "BLUE BACKGROUND" to "OFF".

- 1 Press VCR, then DISC/VCR MENU.
- 2 Press ▲/▼ to select "VCR SET UP", then press ►.
- 3 Press ▲/▼ to select "BLUE BACKGROUND", then press ►.
- 4 Select "OFF" (no blue background) or "ON" (blue background on) with ►.
- 5 To end, press STATUS/EXIT.

SELECT ▲ ▼ CHOOSE ►
 STATUS DISPLAY [ON]
 →BLUE BACKGROUND [ON]
 CLOCK DISPLAY [ON]
 END=EXIT

Clock Display

This function allows you to switch the DVD/VCR display off. It is useful in case you feel disturbed by the display-brightness while watching TV in a dark room. It also reduces the power consumption.

- 1 Press VCR, then DISC/VCR MENU.
- 2 Press ▲/▼ to select "VCR SET UP", then press ►.
- 3 Press ▲/▼ to select "CLOCK DISPLAY", then press ►.
- 4 Select "OFF" (no clock display) or "ON" (clock display on) with ►.
- 5 To end, press STATUS/EXIT.

SELECT ▲ ▼ CHOOSE ►
 STATUS DISPLAY [ON]
 BLUE BACKGROUND [ON]
 →CLOCK DISPLAY [ON]
 END=EXIT

Selecting the sound channel

You can select the desired sound channel during playback or while receiving TV channels via the DVD/VCR. This allows you to select a desired language for multi-language transmissions.

- 1 Press AUDIO. This will show the current sound setting.
- 2 Press AUDIO repeatedly until the desired setting appears in the display.

• Reception of stereo broadcasts:

Mode	AUDIO OUTPUT	Display on the TV screen
Stereo	L L Audio	STEREO
	R R Audio	
L	L L Audio	LEFT
	R L Audio	
R	L R Audio	RIGHT
	R R Audio	
Monaural	L L+R Audio	NONE
	R L+R Audio	

• During playback of the recorded video tape in Hi-Fi mode:

Mode	AUDIO OUTPUT	Display on the TV screen
Stereo	L Hi Fi L Audio	STEREO
	R Hi Fi R Audio	
L	L Hi Fi L Audio	LEFT
	R Hi Fi L Audio	
R	L Hi Fi R Audio	RIGHT
	R Hi Fi R Audio	
Monaural	L Normal Audio	MONO
	R Normal Audio	
MIX	L Hi Fi L Audio + Normal Audio	MIXED
	R Hi Fi R Audio + Normal Audio	

• During reception of bilingual broadcasts:

Mode	AUDIO OUTPUT	Display on the TV screen
MAIN	L Main Audio	MAIN
	R Main Audio	
SUB	L Sub Audio	SUB
	R Sub Audio	
MAIN SUB	L Main Audio	MAIN SUB
	R Sub Audio	


Playing a Disc

Basic Playback DVD-V CD VCD MP3 JPEG Windows Media® Audio

Getting Started

Turn on the power of the TV, amplifier and any other components which are connected to the DVD/VCR. Make sure the TV and audio receiver (commercially available) are set to the correct channel.

- 1 Press STANDBY-ON ⏻.
- 2 Press DVD, then OPEN/CLOSE ► to open disc loading tray.
- 3 Place the chosen disc in the tray, with the label facing up.
- 4 Press PLAY ►.
 - The tray will close automatically, and playback will then start from the first chapter or track of the disc. If the playback does not start automatically, press PLAY ►.
 - When you playback the DVD which a title menu is recorded, it may appear on the screen. In this case, refer to **Title Menu**.
- 5 Press STOP ■ to stop playback.



Notes:

- A "prohibited icon" may appear at the top-right on the TV screen during operation, warning that a prohibited operation has been encountered by the DVD/VCR or the disc.
- With DVDs that use some titles for playback program signals, playback may start from the second title, or it may skip these titles.



- During the playback of two layered disc, pictures may stop for a moment. This happens when the 1st layer switches to the 2nd layer. This is not a malfunction.
- DVDs recorded with the NTSC system can playback with this unit via a PAL system TV set.
- Depending on the TV, when playing back a NTSC DVD on a PAL TV, the picture may roll up or down, shrink vertically and black bars may appear at the both top and bottom of the screen.
- It may take a time to deliver the picture or the sound. This is not a malfunction.
- A disc may not play properly if the Disc's recorded area is less than 55mm across.
- Unfinalized discs will not play on this unit.
- Do not glue paper or put stickers on to the Disc. These may damage the Disc, and this player may not read it correctly.

Cancelling and Calling Back PBC Function VCD

When playing Video CDs with PBC function, some operations (e.g. select and repeat tracks) cannot be performed unless the PBC function is cancelled temporarily.

- 1 Insert a Video CD.
 - Title menu will appear on the display.
 - Playback will start automatically.
- 2 Press STOP ■.
- 3 Press the numerical key pads to enter the desired Track number.
 - PBC function is now cancelled and the playback of the Video CD will start.
- 4 To call back PBC function, press STOP ■ twice, and then press PLAY ►.

Playing a Disc

General Features DVD-V VCD

DVD or Video CDs may contain menus to navigate the disc and access special features. Press the appropriate numerical key pads or use ▲/▼/◀/▶ to highlight your selection in the DVD main menu and press OK to confirm.

Note:

- Unless stated, all operations described are based on remote control use. Some operations can be carried out using the menu bar on the TV screen.

Pause DVD-V CD VCD MP3 JPEG Windows Media™ Audio

- During playback, press PAUSE **II**.
 - Playback will pause and sound will be muted.
 - Pressing PAUSE **II** once during Dual Playback will pause a JPEG file only. Pressing PAUSE **II** one more time will pause an MP3 track.
- To continue playback, press PLAY **▶**.

Note:

- Set "STILL MODE" to "FIELD" in the Display menu if pictures in the pause mode are blurred. (Refer to Display Setting.)

Disc Menus DVD-V

- Press DVD, then DISC/VCR MENU.
 - The DVD main menu will appear.
- If the feature is not available, "☒" symbol may appear on the TV screen.
- If disc menu is available on the disc, audio language, subtitle options, chapters for the title and other options will appear for selection.
- Press ▲/▼/◀/▶ to select an item, and OK to confirm selection.

Title Menu DVD-V

- Press DVD, then TITLE.
 - The title menu will appear.
- If the feature is not available, "☒" symbol may appear on the TV screen.
- Press ▲/▼/◀/▶ to select an item, and OK to confirm selection.
 - Playback will begin at the selected Title.

VCD

- Insert a Video CD.
- The title menu will appear.
- Press numerical key pads to select the menu.
 - Playback will start.

Calling Up a Menu During Playback DVD-V

- Press DISC/VCR MENU to call up the DVD main menu.
- Press TITLE to call up the title menu.

Note:

- Contents of menus and corresponding menu operations may vary between discs. Refer to the manual accompanying the disc for details.

Step by Step Playback DVD-V VCD

- During playback, press PAUSE **II**.
 - Playback will pause and sound will be muted.
- The disc goes forward by one frame each time PAUSE **II** is pressed.
- To exit step by step playback, press PLAY **▶**.

Note:

- Set "STILL MODE" to "FIELD" in the DISPLAY menu if pictures during step by step playback are blurred. (Refer to Display Setting.)

Resume DVD-V CD VCD MP3 JPEG Windows Media™ Audio

- During playback, press STOP **■**.
 - Resume message will appear on the TV screen.
- Press PLAY **▶**, playback will resume from the point at which playback was stopped.
 - To cancel resume, press STOP **■** twice.

Notes:

- For MP3, JPEG and Windows Media™ Audio Tracks, playback will resume from the beginning of the track at which playback was stopped.
- The resume information will be saved even when the power is turned off.

Fast Forward / Reverse Search DVD-V CD VCD MP3 Windows Media™ Audio

- During playback, press **▶▶** or **◀◀** repeatedly to select the required forward or reverse speed.
 - For DVDs and Video CDs, fast forward or reverse search speed is different depending on the disc.
 - For DVDs, approximate speed is 1 (x2), 2 (x8), 3 (x20), 4 (x50), and 5 (x100).
 - For Video CDs, Audio CDs, MP3 or Windows Media™ Audio playback, approximate speed is 1 (x2), 2 (x8), and 3 (x30).
- To return to normal playback, press PLAY **▶**.

Notes:

- If you use **▶▶** or **◀◀** during Dual Playback, JPEG playback will be paused.

Slow Forward / Slow Reverse DVD-V VCD

- During playback, press PAUSE **II**.
- Press **▶▶** or **◀◀**.
 - Slow motion playback will begin and sound will be muted.
- Press **▶▶** or **◀◀** repeatedly to select the required speed. Slow forward or reverse speed varies with the disc. Approximate speed is 1 (1/16), 2 (1/8), and 3 (1/2).
- To return to normal playback, press PLAY **▶**.

Notes:

- Slow Reverse is not available on Video CDs.
- Set "STILL MODE" to "FIELD" in the DISPLAY menu if pictures in the slow motion playback mode are blurred. (Refer to Display Setting.)

Zoom DVD-V VCD JPEG

The Zoom function allows you to enlarge the video image and to pan through the enlarged image.

- Press ZOOM during playback.
 - Playback will continue.
- Press ZOOM repeatedly to select the required zoom factor: x2, x4 or OFF.
- Press ▲/▼/◀/▶ to move the zoomed picture across the screen.
- To exit zoom mode, press ZOOM to OFF.

Notes:

- If you press OK while in the zoom mode, the zoom position window appears at the bottom-right on the TV screen. If you press it again, that (the zoom position) window disappears.
- Zooming function does not work while disc menu is shown.
- x4 zoom is not available on some discs.
- only x2 zoom is available on Video CDs and JPEG CDs.
- Position guide is not available for JPEG playback.

Track Search CD VCD MP3 JPEG Windows Media™ Audio

There are three ways to begin the playback of a specific track.

Using the Numerical key pads

- Press the numerical key pads to enter the desired Track number.
 - Playback will start at the selected track.
 - For single digit tracks (1-9), press a single number (e.g. To play track 3, press 3).
 - To play track 26, press **+10, 2, 6**. (Each number must be pressed within 30 seconds of the previous number.)

Using SEARCH MODE

- Press SEARCH MODE.
 - The Track Search display appears.
- Within 30 seconds, select a desired track number using the numerical key pads. For single or two digit track number, press 0 first.
 - Playback will start at the selected track.

Using **▶|◀** buttons.

During playback, press **▶|** to move to the next track. Press it repeatedly to skip subsequent tracks. Press **|◀** to go back to the beginning of the current track. Press it repeatedly to go back to the previous tracks.

- Track number will appear briefly on the front panel display.
- If **▶|** is pressed while the playback is paused, the playback will be paused again after skipping to the next track.


Note:

- **▶|◀** are not available when playback is stopped.
- **▶|◀** only affect MP3 tracks during Dual Playback.

Playing a Disc

Title / Chapter Search

- 1 Press SEARCH MODE once for the Chapter search, **twice** for the Title search during playback.
- 2 Enter the desired chapter/title number using numerical key pads.



Using the Numerical key pads

- 1 During playback, press the numerical key pads to enter the desired chapter number.
 - Playback will start at the selected chapter.
 - For single digit chapters (1-9), press a single number (e.g. To play chapter 3, press **3**).
 - To play chapter 26, press **+10, 2, 6**. (Each number must be pressed within 30 seconds of the previous number.)

Notes:

- Depending on the disc being played, using the numerical key pads cannot be performed.

Using buttons

During playback, press  to go to the next chapter. Press it repeatedly to skip subsequent chapters. Press  to go back to the beginning of the current chapter. Press it repeatedly to go back to the previous chapter.

Time Search

- 1 During playback, press SEARCH MODE repeatedly until the Time Search screen appears on the TV screen.
- 2 Within 30 seconds, enter a desired disc time using the numerical key pads.
 - Playback will start at the specified time.
 - For DVDs, enter a desired time of the current title.
 - For audio CDs and Video CDs, enter a desired time of the current track.
- 3 Press CLEAR to erase the incorrect input.

Notes:

- "0" appears automatically when there is no need to enter a number. For example, "0:0:_" appears automatically in the Time Search display if the total time of the disc is less than 10 minutes.
- Time Search is not available on some discs.

Repeat

- Repeat is available only during playback.
- The Repeat setting will be cleared when moving to other title, chapter, track, or group.


Repeat Title / Chapter

To activate the repeat function, press REPEAT during playback.

- The repeat mode changes as described below every time you press the button.

Notes:

- Repeat Title/Chapter is not available with some scenes.



Repeat Track / Group / All

To activate the repeat function, press REPEAT during playback.

- The repeat mode changes as described below every time you press the button.

Notes:

- Repeat playback does not function during repeat A-B playback.
- Repeat playback is not available when you play the Video CD with PBC function.



- If you choose Group Repeat during Dual Playback, all Tracks or files in each Folder will play repeatedly.

Repeat A-B

- 1 Press REPEAT A-B at your chosen starting point.
 - A- appears briefly on the TV screen.
- 2 Press REPEAT A-B again at your chosen end point.
 - A-B appears briefly on the TV screen, and the repeat sequence begins.
- 3 To exit the sequence, press REPEAT A-B.


Notes:

- The repeat A-B section can only be set within the current title (for DVDs), or current track (for Audio CDs).
- Repeat A-B is not available with some scenes in DVD.
- To cancel the A point which was set, press CLEAR.
- Repeat A-B playback does not function during title, chapter, track or all repeat playback.

Programmed Playback

You may determine the order in which tracks will be played.

- 1 In stop mode, press MODE.
 - The PROGRAM screen will appear.
- 2 Press  or  to select a track, then press OK.
 - Up to 99 programmes can be stored.
 - Press CLEAR to erase the most recently entered programme.
 - To erase all programmes at once, select "ALL CLEAR" at the bottom of the list and press OK.
 - When selecting an MP3, JPEG or Windows Media™ Audio file or folder, use Arrow as follows:
Press  to go to the next level.
Press  to go back to the previous level.
 - To check programmed tracks or files, ,  to change the pages.
- 3 Press PLAY  to start the programmed playback.



Example: Audio CD

Notes:

- While a programme is being played back, STOP  works as follows:
Press STOP , and then PLAY  next, so that the programmed playback restarts.
(CD playback restarts from the current position. MP3, JPEG and Windows Media™ Audio playback restarts from the beginning of the current track.)
Press STOP  twice and PLAY  next, so that playback restarts from the first track in the original order. However, your programmed playback can be restarted when you follow the above steps. (Your programmes are still stored unless either the disc tray is open or the unit is turned off.)
- To repeat the current track in the program, press REPEAT repeatedly until  TRACK appears during playback.
- To repeat the entire programme press REPEAT repeatedly until  ALL appears during playback.
- Program playback of MP3, JPEG, or Windows Media™ Audio Tracks is not available while Dual Playback is ON.


Random Playback

This shuffles the playing order of tracks instead of playback in the sequence.

- 1 In stop mode, press MODE **twice**.
 - RANDOM screen appears.
- 2 Press PLAY  to start random playback.

Note:

- If you like to repeat the current track in the random selection, press REPEAT repeatedly until  TRACK appears during playback. If you like to repeat the entire random selection press REPEAT repeatedly until  ALL appears during playback.
- Random playback of MP3, JPEG, or Windows Media™ Audio Tracks is not available while Dual Playback is ON.




Example: Audio CD

Playing a Disc

MP3/JPEG/Windows Media™ Audio Playback

Insert an MP3, JPEG or Windows Media™ Audio disc, then press MENU to call up the MP3 or JPEG menu on the TV screen.

- In stop mode, press ▲ or ▼ to select the desired group, MP3 track or JPEG file.
 - If a group is selected, press PLAY ► or OK to go on to the track selection screen. Press ▲ or ▼ to choose a track, then press PLAY ► or OK.
 - If a track is selected, press PLAY ► or OK to start playing from the track.
 - Press TITLE to return to the first item.
- Press STOP ■ to stop playback.



Notes:

- Folders are known as Groups; files are known as Tracks.
 - The "□" symbol is shown on the top of the group name.
 - The "■" symbol is shown on the top of MP3 files.
 - The "□" symbol is shown on the top of JPEG files.
 - The "■" symbol is shown on the top of Windows Media™ Audio files.
 - MP3 or JPEG files recorded on a DVD will not play on this unit.
 - Windows Media™ Audio files recorded on a DVD/CD will not play on this unit.
 - The system can recognise up to 255 groups/ folders and up to 999 tracks/ files, and this applies even to the case where mixed MP3, JPEG and Windows Media™ Audio files are recorded.
 - Up to 8 hierarchies can be created.
 - If a JPEG file is selected, the image will be reproduced from the selected track and go to the next one in turn. A track is displayed for five seconds and then the next track is displayed.
 - Each press on the cursor button ► will rotate the image clockwise by 90 degrees when an image is displayed. Each press on the cursor button ◀ will rotate the image counterclockwise by 90 degrees.
 - Progressive JPEGs (JPEG files saved in the progressive format) will not play on this unit.
 - Copyright protected Windows Media™ Audio files will not play on this unit.
 - High resolution JPEG files takes longer to be displayed.
- For best results use files recorded at these specifications:

[MP3]

- Sampling frequency: 44.1kHz or 48kHz
- Constant bit rate: 32kbps ~ 320kbps.

[JPEG] size of image

- Upper limit: 6,300 x 5,100 dots.
- Lower limit: 32 x 32 dots.

[Windows Media™ Audio]

- Sampling frequency: 44.1kHz or 48kHz
- Constant bit rate: 48kbps ~ 192kbps.

Slide Show Mode

You can switch to the slide show mode during playback.

- Press MODE during playback.
 - The slide show mode screen will appear.
 - The slide show mode cannot be switched when it is stopped, or from the file list screen.
- Press ◀, ► or OK to switch the mode.
 - "CUT IN/OUT": The entire image appears in one time.
 - "FADE IN/OUT": The image appears gradually and then disappears.
- Press MODE to exit.

Dual Playback

- Press DISC/VCR/MENU during MP3/JPEG playback.
 - The file list will appear.
- Press ▲ or ▼ to select a desired JPEG file or MP3 track from the file list, and then press PLAY ► or OK.
 - Dual Playback will begin. Refer to page 18 on how to set the Dual Playback "ON" or "OFF".
- Press STOP ■ to stop playback.

Folder Playback

This function is available only when Dual Playback is ON. You may select to play a folder.

- In Stop mode, press MODE.
 - The folder list will appear.

- Press ▲ or ▼ to select a folder, and then press PLAY ► or OK.
 - MP3 tracks and JPEG files in the selected folder will play simultaneously.
- Press MODE again to exit.

Notes:

- If you press PLAY ► directly after you inserted a disc which contains both MP3 tracks and JPEG files and if the Dual Playback setting is "ON", Dual Playback will start automatically.
- Zooming or rotating a JPEG file during Dual Playback may cause an intermittent sound.
- You can not play Windows Media™ Audio and JPEG files together at the same time. If you choose a Windows Media™ Audio file during Dual Playback, only Windows Media™ Audio file will play.
- Dual Playback may not function properly if MP3 and JPEG files on the disc interfere each other due to the difference in their data size.

Adjustment of Picture Size

Depending on the TV connected to this unit, the overall picture cannot be displayed and the edge of the picture can be cut out. In this case, you can adjust the size of the JPEG playback image on screen.

- During playback, press MODE repeatedly until the picture size appears.
 - The setting screen will not be displayed while in the stop mode or from the file list.
- Press ◀, ► or OK to switch the size.
 - NORMAL : to display the image at 100% of the picture size.
 - SMALL : to display the image at 95% of the picture size.
- Press MODE to exit.

Notes:

- The default setting is "NORMAL".
- This feature may have no effect on some files (e.g. Files with a small picture size).

On-Screen Information

During playback press DISPLAY repeatedly to see the information of the disc currently in play. The information will be displayed in the following order.



- Current chapter number, the elapsed and remaining time of the chapter, and the playback status.
- Current title number, the elapsed and remaining time of the title, and the playback status.
- The BIT RATE and the repeat status, the layer number, and the playback stats.
 - If you are playing a dual layered disc, the layer number will also be displayed (L0: Layer 0 is playing. L1: Layer 1 is playing).



- Current track number, the elapsed and remaining time of the track, and the playback status.
- Current track number, the elapsed and remaining time of the entire disc, and the repeat and the playback status.



- The name of the file/track currently in play (MP3/Windows Media™ Audio/JPEG), and the playback status.
- The name of the title currently in play, and the playback status (Windows Media™ Audio).
- The name of the artist currently in play, and the playback status (Windows Media™ Audio).
- Track number, the elapsed time of the track (MP3), the repeat status, and the playback status (MP3/Windows Media™ Audio/JPEG).
- Program/Random/Folder playback status (only during program, random, or folder playback).
 - Program and Random Playback status will appear only when Dual Playback is OFF.
 - Folder Playback status will appear only when Dual Playback is ON.

Playing a Disc

Hints for the On-Screen Display

- $\hookleftarrow$ C - indicates Chapter repeat.
- $\hookleftarrow$ T - indicates Title / Track repeat
- $\hookleftarrow$ G - indicates Group (folder) repeat
- $\hookleftarrow$ A - indicates Disc repeat
- A $\hookleftarrow$ B - indicates A-B repeat

Notes:

- For MP3 files recorded with Variable Bit Rate (VBR), the elapsed time displayed on the screen may vary from the actual elapsed time.

Audio Language

The DVD/VCR allows you to select a language during DVD disc (if multi language available) playback.

- 1 Press AUDIO during playback.
- 2 Press AUDIO repeatedly to select your desired language.

Note:

- If your language is not shown after pressing AUDIO several times, the disc may not have that language. However, some discs allow you to change audio language or subtitle language setting in the disc menu. (Operation varies depending on the disc, so refer to the manual included in the disc.)

- If you choose a Language that has a 3-letter language code, the code will be displayed every time you change the Audio language setting. If you choose any other languages, '---' will be displayed instead. (Refer to the language code list on page 20.)

Stereo Sound Mode

- 1 Press AUDIO repeatedly during playback to select between "STEREO", "L-ch" or "R-ch".
STEREO - both right and left channels are active (stereo)
L-ch - only left channel is active
R-ch - only right channel is active

Subtitle Language

The DVD/VCR allows you to select a language for subtitle during DVD disc (if available) playback.

- 1 Press DVD, then SUBTITLE during playback.
- 2 Press SUBTITLE repeatedly to select your desired subtitle language.
• The selected language will be displayed on the display bar at the top of the screen.
- 3 To turn off subtitles, press SUBTITLE repeatedly until "OFF" appears.

Note:

- If your language is not shown after pressing SUBTITLE several times, the disc may not have that language. However, some discs allow you to change audio language or subtitle language setting in the disc menu. (Operation varies depending on the disc, so refer to the manual included in the disc.)

Camera Angle

Some DVD discs contain scenes which have been shot simultaneously from various angles. You can change the camera angle when the mark () appears on the screen.

If the "ANGLE ICON" setting is "OFF", the icon () will not appear. (Refer to Display Setting.)

- 1 Press DVD, then ANGLE during playback.
• The selected angle will be displayed on the display bar at the top of the screen.
- 2 Press ANGLE repeatedly to select your desired angle.

Virtual Surround

You can enjoy stereophonic visual space on your existing stereo system.

- 1 Press MODE during playback.
- 2 Press $\blacktriangleleft$, $\blacktriangleright$, or OK to set it "1"(Natural effect), "2"(Emphasised effect) or "OFF".
- 3 Press MODE or RETURN to exit.



Note (for Audio CD and Video CD playback):

- Virtual Surround will not be effective if the sound mode is set to something other than "STEREO".

Marker Setup Screen

Use markers to memorise your favourite places on a disc.

- 1 During playback, press MARKER. The Marker Setup screen appears on the TV screen.
- 2 Press $\blacktriangleleft$ or $\blacktriangleright$ to select 1, 2, 3, 4, 5, 6, 7, 8, 9, or 10 and ensure that "-----" appears in the display.
- 3 When you reach the desired point, press OK.
• The Title or Track and elapsed time will appear on the TV screen.
- 4 To return to a marker later, press MARKER. The Marker Setup screen appears and $\blacktriangleleft$ or $\blacktriangleright$ to choose the desired marker, then press OK.

Notes:

- Opening the disc tray, turning off the power or selecting "AC" at step 2 and press OK will erase all markers.
- To clear a marker, using $\blacktriangleleft$ or $\blacktriangleright$, position the cursor on to the marker number to be cleared and press CLEAR.
- You can mark up to 10 points.

- 5 Press MARKER or RETURN to exit.

DVD Setup

Language Setting

Language options are not available with some discs.

- 1 Press SYSTEM MENU in stop mode.
- 2 Press $\blacktriangleright$ to select CUSTOM, then press OK.
• CUSTOM mode will appear.
- 3 Press $\blacktriangleleft$ or $\blacktriangleright$ to select "LANGUAGE", then OK to confirm.
- 4 Press $\blacktriangle$ or $\blacktriangledown$ to select the below items, then press OK.

AUDIO :

Sets the audio language.

SUBTITLE :

Sets the subtitle language.

DISC MENU :

Sets the language for DVD Menu.

PLAYER MENU : QUICK

Sets the language for the On-Screen display.

- 5 Press $\blacktriangle$ or $\blacktriangledown$ to select a setting, then press OK.
• If "OTHER" is selected in the AUDIO, SUBTITLE or DISC MENU screen, press 4-digit number to enter the code for the desired language.
(Refer to the language code list on back inside cover).
• Only the languages supported by the disc can be selected.
- 6 Press SYSTEM MENU to exit.


Note:

- Even if DVDs contain multiple audio or subtitle languages, language setting screen for "AUDIO" or "SUBTITLE" may not be available with some discs.
Then, use AUDIO or SUBTITLE.
(Refer to Audio Language/Subtitle Language.)

Display Setting

You can change the display functions.

- 1 Press SYSTEM MENU in stop mode.
- 2 Press $\blacktriangleleft$ or $\blacktriangleright$ to select CUSTOM, then press OK.
• CUSTOM mode screen will appear.
- 3 Press $\blacktriangleleft$ or $\blacktriangleright$ to select "DISPLAY", then OK to confirm.
- 4 Press $\blacktriangle$ or $\blacktriangledown$ to select the below items, then press OK.
- 5 Press SYSTEM MENU to exit.



TV ASPECT : QUICK

4:3 LETTER BOX : when viewing a 16:9 picture on a 4:3 aspect TV screen, black bars appear on the top and bottom of the screen.

4:3 PAN & SCAN : when viewing a 16:9 on a 4:3 aspect TV screen, a full height picture with both sides trimmed is presented.

16:9 WIDE : if a wide-screen TV is connected to this unit, select this setting.

- Press $\blacktriangle$ or $\blacktriangledown$ to select a setting, then press OK.
- The default setting is "4:3 LETTER BOX".

STILL MODE :

AUTO : select it usually.

DVD Setup

- FIELD** : pictures in the Still mode will be stabilised although they will be coarse due to a little amount of data.
- FRAME** : pictures in the Still mode will be highly defined although they will be blurred due to outputting two fields at the same time.

- Press ▲ or ▼ to select an option, then press OK.
- The default setting is "AUTO".

VIDEO OUT :

- AUTO** : to change video out system (PAL/NTSC) automatically according to the format of an inserted disc.
- PAL** : to view pictures of the discs recorded with PAL system.

- Press OK repeatedly to select "PAL" or "AUTO".
- The default setting is "AUTO".

Audio Setting

Choose the appropriate Audio settings for your DVD playback.

- 1 Press SYSTEM MENU in stop mode.
- 2 Press ► to select CUSTOM, then press OK. CUSTOM mode will appear.
- 3 Press ◀ or ▶ to select "AUDIO", then OK to confirm.
- 4 Press ▲ or ▼ to select the below items, then press OK.

DRC (Dynamic Range Control) :

To compress the range of sound volume.

The default setting is "ON".

DOWN SAMPLING :

Set to "ON" when outputting in 48kHz.

The default setting is "ON".

When playing disc with copyright Protection

- If you select "OFF", copyright protection will be activated and sound will be down sampled at 48kHz.

DOLBY DIGITAL :

Set to "BITSTREAM" when the player is connected to Dolby Digital Decoder.

BITSTREAM : Output by Dolby Digital

PCM : Convert the Dolby Digital to PCM

- The default setting is "BITSTREAM".

MPEG :


Set to "BITSTREAM" when the player is connected MPEG Decoder.

BITSTREAM : Output by MPEG

PCM : Convert the MPEG to PCM

- The default setting is "PCM".

- 5 Press SYSTEM MENU to exit.



- 6 Press ▲ or ▼ to select the desired level, then press OK. For details, see below.

- 7 Press SYSTEM MENU to exit.

PARENTAL LEVEL

ALL : All parental locks are cancelled.

8 : DVD softwares of any grades (adult/general/children) can be played back.

7 to 2 : Only DVD softwares intended for general use and children can be played back.

1 : Only DVD softwares intended for children can be played back.

Note:

- This function may not work on some DVDs. Make sure if the parental lock function operates in the way you have set.


To Change the Password

- 1 Follow the steps 1 to 4 above.
- 2 Press ▲ or ▼ to select "PASSWORD CHANGE", then press OK.
- 3 Enter a new 4-digit password, then press OK.
- 4 Press SYSTEM MENU to exit.

Others

You can change the other functions.

- 1 In Stop mode, press SYSTEM MENU.
- 2 Press ◀ or ▶ to select CUSTOM, then press OK.
 - CUSTOM mode screen will appear.
- 3 Press ◀ or ▶ to select "OTHERS", then OK to confirm.
- 4 Press ▲ or ▼ to select the below items, then press OK. Select options following instructions below.
- 5 Press SYSTEM MENU to exit.



ANGLE ICON :

ON : to show the angle icon when multiple camera angles are available during DVD playback.

OFF : to hide the angle icon.

- Press OK repeatedly to select "ON" or "OFF".

• The default setting is "ON".

AUTO POWER OFF :

ON : to turn off the unit automatically after 30 minutes of no use.

OFF : to keep this unit on.

- Press OK repeatedly to select "ON" or "OFF".

• The default setting is "ON".

DUAL PLAYBACK :

ON : to play MP3 tracks and JPEG files simultaneously.

OFF : to play MP3 tracks and JPEG files separately.

- Press OK repeatedly to select "ON" or "OFF".

• The default setting is "OFF".

SLIDE SHOW :

- Press ▲ or ▼ to select "5sec", "10sec" or "MUSIC". Then, press OK.

5sec : to display each image for 5 seconds.

10sec : to display each image for 10 seconds.

MUSIC : to display an image for each MP3 sound file playback when Dual Playback is "ON".

- If you select "MUSIC" when Dual Playback is "OFF", the playback speed will be set to 5 seconds automatically.

• The default setting is "5sec".

To Reset All the Settings of the SET UP screen

- 1 Press SYSTEM MENU in stop mode.
- 2 Press ◀ or ▶ to select INIT., then press OK.
- 3 Press ▲ or ▼ to select "YES", then OK twice. All the settings (except for "PARENTAL") will be cleared.
 - To cancel the initialisation, select "NO".
- 4 Press SYSTEM MENU to exit.

Parental Control

Parental Control limits the DVD viewing that exceeds your settings. The password is required to change the "PARENTAL LEVEL".

This feature prevents your children from viewing inappropriate materials.

- 1 Press SYSTEM MENU in stop mode.
- 2 Press ◀ or ▶ to select CUSTOM, then press OK.
 - CUSTOM mode screen will appear.
- 3 Press ◀ or ▶ to select "PARENTAL", then press OK.
- 4 Press the numerical key pads to enter your 4-digit password.
 - When doing this for the first time, enter any 4-digit number by pressing the numerical key pads (except for 4737), then press OK. That number will be used as the password from the second time onward. Record your password in case you forget it.
 - If you forget the password, press 4, 7, 3, 7. The original password will be cleared and parental levels will be set to "ALL". Enter a new 4-digit password, then press OK.
- 5 Press ▲ or ▼ to select "PARENTAL LEVEL", then press OK.



Maintenance

Cleaning the Cabinet

- Use a soft cloth slightly moistened with a mild detergent solution. Do not use a solution containing alcohol, spirits, ammonia or abrasives.

Cleaning Discs

- When a disc becomes dirty, clean it with a cleaning cloth. Wipe the disc from the centre out. Do not wipe in a circular motion.
- Do not use solvents such as benzine, thinner, commercially available cleaners, or antistatic spray intended for analogue records.

Cleaning the disc lens

- After prolonged use, dirt or dust may accumulate at the disc lens. To ensure good playback quality, clean the disc lens with Philips CD Lens Cleaner or any commercially available cleaner. Follow the instructions supplied with the cleaner.

Specifications

PLAYBACK SYSTEM

DVD Video, Audio CD, DVD+R/RW, DVD-R/RW,
CD-R/RW, Video CD

TV STANDARD (PAL/50Hz) (NTSC/60Hz)

Number of lines 625 525
Playback Multistandard (PAL/NTSC)

VIDEO PERFORMANCE

Video output 1 Vpp into 75 ohm
RGB (SCART) output 0.7 Vpp into 75 ohm
Video Shift Left/Right

VIDEO CASSETTE RECORDER

Video heads 4 heads Hi-Fi
Antenna VHF/UHF - 75 ohm
VHF output 75 ohm unbalanced

AUDIO FORMAT

Digital MPEG Compressed
Digital
Dolby Digital 16, 20, 24 bits
PCM fs, 44.1, 48, 96 kHz

Analogue Stereo Sound

Dolby Surround-compatible downmix
from Dolby Digital multi-channel sound
3D Sound for virtual 5.1 channel sound on 2 speakers

AUDIO PERFORMANCE

DA Converter 24 bits
DVD fs 96 kHz 20 Hz - 44 kHz
fs 48 kHz 20 Hz - 22 kHz
CD fs 44.1 kHz 20 Hz - 20 kHz
Signal-Noise (1kHz) 70 dB
Dynamic Range (1kHz) 90 dB
Distortion and Noise (1kHz) 0.1%

CONNECTIONS

SCART 2x Euroconnector
S-Video Output Mini DIN, 4 pins
Audio L+R output 2x Cinch (white/red)
Digital Output 1 Coaxial, 1 Optical
IEC958 for CDDA / LPCM
IEC1937 for MPEG1/2, Dolby Digital

CABINET

Dimensions (w x h x d) 435 x 94 x 233 mm
Weight Approximately 3.2 kg

POWER SUPPLY (UNIVERSAL)

Power inlet 220 ~ 240 V, 50 Hz
Power usage Approx. 25 W
Power usage standby 14 W
(standby : 5.0 W)
(When CLOCK DISPLAY
set to OFF)

Specifications subject to change without prior notice

Troubleshooting

Problem	Solution
No power	– Check if the AC power cord is properly connected.
No picture	– Check if the TV is switched on. – Check the video connection.
Distorted picture	– Sometimes a small amount of picture distortion may appear. This is not a malfunction.
Completely distorted picture or black/white picture with DVD	– Connect DVD/VCR directly to the TV. – Make sure the disc is compatible with the DVD/VCR.
No sound or distorted sound	– Adjust the volume. – Check that the speakers are connected correctly.
No audio at digital output	– Check the digital connections. – Check if the audio format of the selected audio language matches your receiver capabilities.
No sound and picture	– Check that the SCART cable is connected to the correct device (See Connecting to a TV)
Picture freezes momentarily during playback	– Check the disc for fingerprints/scratches and clean with a soft cloth wiping from centre edge. – This may happen when you use the disc recorded in the non-seamless manner. This is not a malfunction.
Disc cannot be played	– Ensure the disc label is facing up. – Check if the disc is defective by trying another disc.
No return to start-up screen when disc is removed	– Reset the unit by switching the DVD/VCR off, then on again.
The DVD/VCR does not respond to the remote control	– Aim the remote control directly at the sensor on the front of the DVD/VCR. – Reduce the distance to the DVD/VCR. – Replace the batteries in the remote control. – Re-insert the batteries with their polarities (+/- signs) as indicated.
Buttons do not work or DVD/VCR stops responding	– To completely reset the DVD/VCR, unplug the AC cord from the AC outlet for 5-10 seconds.
DVD/VCR does not respond to some operating commands during playback.	– Operations may not be permitted by the disc. Refer to the instructions of the disc.
DVD/VCR cannot read CDs/DVDs	– Use a commonly available cleaning CD/DVD to clean the lens before sending the DVD/VCR for repair.
The DVD/VCR switches from DVD mode to VCR mode after 30 minutes of no activity.	– When AUTO POWER OFF is set to ON, the DVD/VCR switches itself from DVD mode to VCR mode if Disc playback stops for more than 30 minutes and you press no buttons on the remote or the DVD/VCR.
The VCR do not record a TV program	– Make sure the video tape has a record tab. – Make sure the DVD/VCR is in VCR position. – Check the TV and the DVD/VCR channel are similar.
The DVD/VCR do not perform a timer	– Make sure the recording start and stop times are set correctly. – Make sure the video tape has a record tab. – Make sure the clock is set. – The DVD/VCR may not perform or continue a timer recording if the power fails for more than 1 minute.
The motor (cylinder) rotates even when video tape playback is stopped	– To enable quick play mechanism, the cylinder will rotate for about five minutes. This is not a malfunction.
You cannot insert a video tape	– Insert a video tape, window side up with the record tab facing you. – Gently push on the center of the video tape when putting into the DVD/VCR.
You cannot remove a video tape	– Make sure the power plug is completely connected to a power outlet.
DVD/VCR ejects the tape when you press RECORD or TIMER SET for a timer recording.	– Make sure the video tape has a record tab.

If you are unable to remedy a problem by following these hints, consult your dealer or service centre (HOTLINE).

Language	Code	Language	Code	Language	Code	Language	Code
A-B		French [FRE]	5264	Macedonian	5957	Siswat	6565
Abkhazian	4748	Frisian	5271	Malagasy	5953	Slovak	6557
Afar	4747	Galician	5358	Malay	5965	Slovenian	6558
Afrikaans	4752	Georgian	5747	Malayalam	5958	Somali	6561
Albanian	6563	German [GER]	5051	Maltese	5966	Spanish [SPA]	5165
Amharic	4759	Greek [GRE]	5158	Maori	5955	Sundanese	6567
Arabic	4764	Greenlandic	5758	Marathi	5964	Swahili	6569
Armenian	5471	Guarani	5360	Moldavian	5961	Swedish [SWE]	6568
Assamese	4765	Gujarati	5367	Mongolian	5960	T	
Aymara	4771	Hausa	5447	Nauru	6047		Tagalog
Azerbaijani	4772	Hebrew	5569	Nepali	6051	Tajik	6653
Bashkir	4847	Hindi	5455	Norwegian [NOR]	6061	Tamil	6647
Basque	5167	Hungarian [HUN]	5467	O-R		Tatar	6666
Bengali;Bangla	4860	I-K			Occitan	6149	Telugu
Bhutani	5072		Icelandic [ICE]	5565	Oriya	6164	Thai
Bihari	4854	Indonesian	5560	Oromo(Afan)	6159	Tibetan	4861
Bislama	4855	Interlingua	5547	Panjabi	6247	Tigrinya	6655
Breton	4864	Interlingue	5551	Pashto;Pushto	6265	Tonga	6661
Bulgarian	4853	Inupiak	5557	Persian	5247	Tsonga	6665
Burmese	5971	Irish [IRI]	5347	Polish	6258	Turkish [TUR]	6664
Byelorussian	4851	Italian [ITA]	5566	Portuguese [POR]	6266	Turkmen	6657
C-E		Japanese [JPN]	5647	Quechua	6367	Twi	6669
		Javanese	5669	Rhaeto-Romance	6459	U-Z	
Cambodian	5759	Kannada	5760	Romanian [RUM]	6461		Ukrainian
Catalan	4947	Kashmiri	5765	Russian [RUS]	6467	Urdu	6764
Chinese [CHI]	7254	Kazakh	5757	S		Uzbek	6772
Corsican	4961	Kinyarwanda	6469		Samoan	6559	Vietnamese
Croatian	5464	Kirghiz	5771	Sangho	6553	Volapuk	6861
Czech	4965	Kirundi	6460	Sanskrit	6547	Welsh	4971
Danish [DAN]	5047	Korean [KOR]	5761	Scots Gaelic	5350	Wolof	6961
Dutch [DUT]	6058	Kurdish	5767	Serbian	6564	Xhosa	7054
English [ENG]	5160	L-N		Serbo-Croatian	6554	Yiddish	5655
Esperanto	5161		Laothian	5861	Sesotho	6566	Yoruba
Estonian	5166	Latin	5847	Setswana	6660	Zulu	7267
F-H		Latvian;Lettish	5868	Shona	6560		
		Lingala	5860	Sindhi	6550		
Faroese	5261	Lithuanian	5866	Singhalese	6555		
Fiji	5256						
Finnish [FIN]	5255						